



# 信号区


用户按键




POWER




PB6-PB9




PA15-PB5




PC10-PD2



PA11-PA14




PC9-PA10




PB14-PC7




状态指示




PC13-NRST




CAN1 Transceiver




CAN扩展板接口




RGB指示



PC0-PC3




VDD滤波




VDDA滤波



CAN2 Transceiver




上拉电阻




BOOT选择




PA0-PA3




PA4-PA7




PC4-PB1




PB10-PB13




USB Terminator



USB保险丝




USB接口




# 电源区



DCDC+LDO



ST-LINK



UART1-6接口



Title		HWSD-DEV Series-F405	
Size	Number	Revision	
A2		V1.0	
Date:	21/8/2022	Sheet of	
File:	C:\Users\HWSD-Develop\SCH\SchDoc\Drawn By:	ASR-Czsh	